


PARASOL Z VAV d

Technical manual

09/01/2023

Content

| | |
|---|-----------|
| Installation and safety..... | 3 |
| Function in the room | 4 |
| General | 4 |
| Functional description air | 4 |
| Functional description water | 4 |
| Adaptation as required | 5 |
| Distribution of the air flows | 6 |
| Configuration and settings | 8 |
| Sequences | 11 |
| Technical description | 13 |
| Sensor module overview | 13 |
| Sensor module occupancy | 13 |
| Sensor module temperature..... | 14 |
| Regulator overview | 15 |
| Regulator outputs..... | 16 |
| Regulator inputs | 17 |
| Regulator's Modbus connections | 18 |
| Systems Engineering | 19 |
| Duct system..... | 19 |
| 2-step optimisation in WISE gen.1 | 22 |
| Master/Slaves..... | 24 |
| Display in Super Wise..... | 25 |
| IC Design..... | 26 |
| Sizing and hardware configuration | 26 |
| Heat with PARASOL Zenith VAV | 27 |
| Air quality sensor..... | 28 |
| General | 28 |
| Data entry in SWICCT: | 28 |
| Change –over system | 29 |
| 2-pipe system with cooling in the summer and heating in the winter | 29 |
| Control of the lighting..... | 30 |
| Start-up and Zero point calibration..... | 30 |
| Two-stage cooling/two stage heating | 31 |
| Modbus register..... | 32 |
| Trouble shooting..... | 40 |
| Alarm List | 40 |



Installation and safety

About this manual

This manual is intended for technicians or those with the equivalent knowledge who work in design, commissioning, maintenance or for some other reason need a more technical description of the product than offered by a product data sheet.

The manual contains information about:

Technical description.

Help during project design

Installation and start-up

Instruction about how the different settings are made

Changing the project

Swegon reserves the right to make changes to both the manual and to the product without prior notice.

Safety Instructions

Responsibility

It is the user's responsibility to:

- Make all relevant risk assessments of the activities that are related with this manual.
- Ensure that all necessary safety precautions have been taken before the activities related with this manual are started.

Function in the room

General

PARASOL Zenith VAV is a four-way blowing comfort module with built-in control equipment for demand-control not only of the air but also the entire indoor climate in the room.

The product can work as a stand-alone unit or connectable to BMS via ModBUS or connected in a system such as Swegon's WISE gen.1.

Function of the product is based on a constant duct pressure being provided either through a zone damper such as CONTROL Zone or in a smaller system with a unit that can maintain the duct pressure sufficiently constant.

In a room where the occupancy rate is low and/or uneven PARASOL Zenith VAV can, in the event being unoccupied, save air through the integrated damper and also allow the temperature to deviate more from the room's setpoint than with occupancy, all to save energy.

On occupancy the integrated control equipment quickly takes care of the indoor climate by opening the damper and the cooling or heating valves so that a comfortable indoor climate with high comfort is maintained - yet still with minimal energy input.

A sensor module with temperature and presence sensors registers what is happening in the room and act at the same time as setpoint selector and alarm indicator.

Functional description air

The product regulates the amount of air to the room according to three levels:

- Unoccupied
- Min. occupancy
- Max. occupancy

For **Unoccupied mode** a low air flow is supplied to save air. When someone enters the room the occupancy is detected by the presence sensor integrated in the sensor module and the air flow is increased to the **Min. occupancy** level.

In addition to an presence sensor there is also a temperature sensor in the sensor module that measures the temperature of the room air. When the temperature exceeds the desired setpoint in the room, the PARASOL Zenith VAV starts to cool, either with air first, or water depending which the chosen sequence selection. When the output demand becomes large enough, or air quality is poor enough, PARASOL Zenith VAV will variably open up to **Max occupancy** air flow.

Functional description water

Different temperature settings can be set for

- Unoccupied
- Occupancy
- Holiday mode, i.e. extended unoccupied mode
- In the case of **unoccupied mode** the temperature can be allowed to deviate more from the room's set-points than for occupancy. When someone enters the room and the sensor module indicates **occupancy** the PARASOL Zenith VAV is set to normal operation mode and then regulates the desired room temperature more accurately. **Holiday mode** works in the same way as unoccupied mode, but here the temperatures are permitted to deviate further from the room's set-point and a signal from a master system is required
- Heating and cooling are controlled in sequence to avoid simultaneous cooling and heating. However, there is a cold draught protection that can be activated and this then means that you allow a certain amount of heat simultaneously with cooling.

Adaptation as required

During a day different things occur that affect the room's climate, and PARASOL Zenith VAV uses both air and water to maintain a good climate:



- Night, no occupancy in the room
- The temperature is permitted to deviate slightly more from the setpoint than for occupancy
- Air flow "unoccupied"



- Morning, no occupancy
- Air flow "unoccupied"
- The temperature is still regulated according to the settings for unoccupied, but if a cooling demand occurs e.g. due to solar incident radiation PARASOL Zenith VAV will start to cool the room.



- Morning, the workday begins and someone enters into the room.
- The sensor module detects occupancy and the air flow rises to the set Min Occupancy flow, which is the minimum air flow in the room when someone is present.
- The temperature is now allowed to deviate less from the setpoint value than in unoccupied mode.



- Different things can happen during the day that change the room's climate, such as increased solar incident radiation or increased sensory pollution loads from occupants.
- PARASOL Zenith VAV can now manage this by opening the water valve in combination with variably regulating the air flow towards the Max Occupancy flow.

Distribution of the air flows



The principle is the same for a conference room or a landscape office.

When several PARASOL Zenith VAVs need to cooperate in a room the air flow is evenly distributed between them.


One product is then defined as the master while the others become slaves.

If the room is large and there is a great distance between products, it may be an alternative to allow all the units to be Masters, i.e. all are regulated independently of each other. Different parts of the room can then have different climates, which may be the intention, but you also risk supplying the room as a whole with both cooling and heating simultaneously.

Master and Slave(s) share the room's supply air flow proportionally. Proportionally as two different PARASOL Zenith VAVs, e.g. 600 and 1200 can have different maximum flows.

Example: If a 600 gives a maximum of 25 l/s and a 1200 max 40 l/s and the room's total supply air flow at one time is 30 l/s, the 600 will give approx. 12 l/s and the 1200 about 18 l/s. Had both been identical they would have given 15 l/s each.

The extract air constantly receives a signal from the master, a signal voltage of 2-8 V, which is converted from the master's flow.




PARASOL Zenith VAV works perfectly as a standalone unit, i.e. without a connection to the master system. The simplest solution on offer is that shown in the picture, a room with PARASOL Zenith VAV and extract air via the air transfer unit. Air balancing occurs on a zone level and PARASOL Zenith VAV demand-controls the climate in the room.

1. Comfort module PARASOL Zenith VAV with supply air, cooling and heating Incl.
 - pressure sensor
 - communications unit/regulator
 - damper with motor.
2. Zone damper CONTROL Zone
3. Extract air diffuser
4. Cooling water and heating water
5. Extract air via transfer air to the corridor
6. External Sensor module (occupancy and temperature sensors)


Since heating is provided from PARASOL Zenith VAV in the case above, the sensor module is positioned on the wall.

Distribution of the air flows


Office - Unoccupied




Conference room - Unoccupied




Office - Min. Occupancy




Conference room - Min. Occupancy



Office - Max. Occupancy




Conference room - Max. Occupancy




Configuration and settings

The following pages show a room with PARASOL Zenith VAV Master, PARASOL Zenith VAV Slave and ADAPT Damper slave/extract air and the settings you should remember to set on each unit to get the room to perform as intended.



Master: All settings for the room; temperature, air flow etc. are made here.

- Output no. 19 is set to "ADAPT analogue extract air" to send the control signal to the extract air damper.
- Modbus address 4, 8, 12 etc. as per SuperWISE std.
- Pressure sensors and sensor module are addressed 0 with the dial.
- K-factor of master products



SWICCT


| Airflow settings | | |
|---------------------------|-----|---------|
| K-factor min flow | 0 | k*100 |
| K-factor max flow | 416 | k*100 |
| Zero cal. pressure sensor | | |
| Airflow setpoint UNOCC. | 50 | l/s *10 |
| Airflow setpoint OCC. | 40 | l/s *10 |
| Airflow setpoint MAX | 200 | l/s *10 |
| Airflow setpoint HOLIDAY | 320 | l/s *10 |
| Min cooling Pressure | 200 | dpa |
| ADAPT EA analog min | 200 | l/s *10 |
| ADAPT analog max | 400 | l/s *10 |
| ADAPT EA offset | 0 | %* 100 |

K-factor of current product

Total air flow for the room


Working range for the extract air damper

Configuration and settings



Slave:

- Output no. 13 is set to “ADAPT slave supply air” to slave control the damper signal from the master.
- The Modbus ID is set between 1-9, not connection to SuperWISE.
- Addressing of the pressure sensors via the dial should always follow the slave unit’s Modbus ID 1-9. Addressing of the sensor module ideally follows the same pattern, but is not required. Crucially, two sensor modules must not have the same address if they are connected on the same circuit as in this case with master/slave in the room. The regulator on the slave unit serves in this case as the connection point, all intelligence is used in the master unit. However, if the room in the future is fitted with a partition, the unit can be easily reconfigured as the master in its room. The sensor module connected to the slave unit reports occupancy and temperature to the master.
- K-factor for the PARASOL Zenith VAV slave must be fed into its regulator



Extract air:

Set to extract air, Temp Sensor Use = 1 med TUNE Adapt/ SuperWISE

Must be “slave” (Application type = 3), changed as necessary with the help TUNE Adapt/SuperWISE

Modbus address 5, 6, 7, 9, 10, 11, etc. as per SuperWISE std.

The damper is delivered in commissioning mode = fully open, must be set in “normal”/commissioning = “inactive”.

The right size of damper for the extract air is selected using the product sheet for ADAPT Damper.

All dampers have default settings for unoccupied, min. occupancy and max. occupancy. These values (or new if they have been changed) must be specified in the software settings for PARASOL Zenith VAV master in the room, see the description of Master on page 8 and extract air page 10.

Configuration and settings

Continued, extract air

Example:

Assume that the room shown with PARASOL Zenith VAV master + slave + ADAPT Damper extract air slave must have the flows

Unoccupied = 12 l/s

Min. occupancy = 25 l/s

Max. occupancy = 60 l/s

By stating the extract air damper's Min. and Max. flow rate in the PARASOL Zenith VAV master (via SWICCT or SuperWISE) this knows what 2 V and 8 V represent for flows on the extract air damper.

The master then converts the inputted room flows (12/60) to an analogue signal between 2-8 V which then slave control the extract air damper. The damper can by means of its flow measurement report back the flow.

ADAPT Damper product sheet:

Standard settings for default products

| Air flows (l/s) | Unoccupied* | Min. air flow | Max. air flow |
|-----------------|-------------|---------------|---------------|
| Size 125 | 0/4 | 8 | 25 |
| Size 160 | 0/6 | 10 | 80 |
| Size 200 | 0/10 | 15 | 125 |

SWICCT, input i PARASOL Zenith VAV master:

Airflow settings

| | | |
|---------------------------|--------------------------|---------|
| K-factor min flow | 0 | k*100 |
| K-factor max flow | 416 | k*100 |
| Zero cal. pressure sensor | <input type="checkbox"/> | |
| Airflow setpoint HOLIDAY | 50 | l/s *10 |
| Airflow setpoint UNOCC. | 120 | l/s *10 |
| Airflow setpoint OCC | 250 | l/s *10 |
| Airflow setpoint MAX | 600 | l/s *10 |
| Min cooling Pressure | 200 | dPa |
| ADAPT EA analog min | 100 | l/s *10 |
| ADAPT EA analog max | 800 | l/s *10 |
| ADAPT EA offset | 0 | %* 100 |

12 l/s = 2.17 V
60 l/s = 6.28 V

2V = 10 l/s
8V = 80 l/s

Note that the extract air damper's work range must be equal or greater than the room flow.

If the extract air flow must be shared by the two ADAPT Dampers, these must be of the same size and it is the total flow of the two dampers that should be entered in the PARASOL Zenith VAV master regulator.

In the above the settings are described based on the ADAPT Damper's default values being used. **These values can be changed as usual with TUNE Adapt or SuperWISE, and then it is these new values that are to be entered in PARASOL Zenith VAV master.**

Sequences

Sequence selection, cooling with Air or Water first.

It is possible to prioritise cooling with water first or air first.


For the sequence selection water/air it applies that the cooling valve is not permitted to open before a given nozzle pressure is reached, this is to ensure that no cold air drops down into the occupancy zone.

The sequence selections are parameter selections in software, i.e. it is the same physical product being delivered from the factory.

The principle is the same irrespective of whether you have one product in the room or several Master/Slaves connected.

Sequence selections are described in the following graphs.

PARASOL Zenith VAV - Sequence Water/Air




1. Occupancy - temperature rises
2. Room temperature reaches the level for the cooling demand - air opens to reach the minimum pressure that permits the cooling valve to open
3. The cooling valve is permitted to open
4. Cooling valve fully open, but there is still a cooling demand in the room - air damper opens to cool with more air
5. Cooling valve and air damper fully open
6. Temperature reaches the room's setpoint, damper and valve starts to close

— Water
— Air
- - - Room temperature


* Min P (Min cooling pressure): minimum permitted nozzle pressure to allow the cooling valve to open, this is to prevent cold draughts when the cold water circulates in the coil. In the event of a too low nozzle pressure and low temperature there is a risk the air drops too early from the ceiling.
20 Pa default but can be changed.

Sequences

PARASOL Zenith VAV - Sequence Air / Water



PARASOL Zenith VAV - Sequence Air quality



Technical description

Sensor module overview

- Temperature and occupancy sensor
- Setpoint selector switch
- Installation on a wall or on the face plate
- Circular or rectangular
- Alarm indication
- Open/close the product's dampers and valves for e.g. function control/commissioning.
- Modbus connected
- Alternative connection point for the connection of a PC for software configuration


Sensor module occupancy

- Occupancy detector of the IR type, i.e. a heat-detecting sensor that quickly reacts to occupancy in the room
- Coverage area depending on the placement in the room, see figure.
- On and off delay adjustable via SWICCT default is 10 s, and 10 minutes respectively
- Several sensor modules can be used in the room, for example, in a conference room if you want the setpoint selector switch on the wall but the presence sensor on the ceiling.

Sensor module front




Sensor module rear




1. Presence sensor / IR sensor
2. LEDs for temperature, adjustment or alarm indication
3. Function keys
4. LED indicating function
Green = OK
Flashing green = Condensation alarm
Yellow = alarm
Green/yellow = Comfort alarm (not acute)
5. Temperature sensor
6. 3 parallel RJ12 ports (Modbus) for connections e.g. regulator, additional sensor module or PC.
7. Addressing the sensor module. A maximum of 10 sensor modules (possibly slaves included) can be connected to each master regulator. Each one must then have its own address 0-9.
8. Switch for termination resistance. Switch 1 is set to On on the last device in a circuit.

Ceiling mounted



| h (m) | d (m) | A (m ²) |
|-------|-------|---------------------|
| 2.5 | 5.2 | 21 |
| 2.7 | 5.6 | 24 |
| 2.9 | 6.0 | 28 |
| 3.1 | 6.4 | 32 |

Wall mounted



Sensor module temperature

Temperature settings

Room temperature sensor use

Mean value of sensor module (s) ▼

Mean value of sensor module (s)

Sensor module id 0

External temperature sensor

Mean value of sensor module(s) and ext.temp.sens.




In SWICCT it is possible to state how you wish to measure the temperature in the room:


- **Mean value of sensor modules:** In cases where multiple sensor modules are connected to the master, for example, when using slave units as on page 24, the mean value of all sensor modules can then be used for temperature control in the room.
- **Sensor module id 0:** the selection means that only one sensor module (the one with id 0, master unit) is used for temperature control.
- **External temperature sensor:** here you state that an external temperature sensor is used, and regulation occurs only according to this sensor.
- **Mean value of sensor modules and ext. Temp. Sens:** signifies that the mean value of both sensor modules and external temperature sensors is used for temperature control.
- The temperature in the room is set by pressing the function buttons (A)=cooling / (B)=heating.
- Both cooling and heating setpoints move, which means that the previously created neutral zone is maintained.
- For example, Cooling Setpoint = 24°C (call for cooling when the room temperature exceeds 24°C) Heating Setpoint 22°C (Start heating when the room temperature is below 22°C).
- Press the sensor module twice to make it warmer means the set values shift 2°C to 24 and 26°C respectively.
- If the desired temperature is not reached after a specific time a comfort alarm is generated, which is indicated by the alarm LED switching between yellow/green.
- Ideally the sensor module can be mounted on a wall where it can be assumed that the room's setpoint needs to be changed often. Normally this need arises only in rooms used by different people with different needs.
- Wall mounting is also recommended when you heat with PARASOL Zenith VAV, usually this gives a fairer measurement of the room temperature.

Wiring diagram

Wiring diagram for accessories




A: Connection when a VOC sensor is used



Regulator outputs

The outputs on the regulator



Outputs' standard settings

Output configuration


| | | |
|-----------------------|-----------------|-------------------|
| Digital output 1 (21) | Water cooling ▼ | Normally closed ▼ |
| Analog output 1 (19) | Not used ▼ | Normally closed ▼ |
| Digital output 2 (18) | Water heating ▼ | Normally closed ▼ |
| Analog output 2 (16) | Not used ▼ | Normally closed ▼ |
| Digital output 3 (15) | Power supply ▼ | Normally closed ▼ |
| Analog output 3 (13) | Variable ▼ | Normally closed ▼ |

The outputs can be switched with SWICCT for alternative functions, for example, the use of a 0-10 V actuator for cooling/heating instead of 24V

| Digital output 1,2,3 (21,18,15) | | Description |
|---------------------------------|----------------------------------|---|
| → | Not used | No signal on the output |
| → | Power supply | 24V constant supply out from the output |
| → | Water cooling | 24V when there is a cooling signal |
| → | Water heating | 24V when there is a heating signal |
| → | Water change over 2 pipe | 24V for cooling/heating demand |
| → | Water cooling primary sequence | Cooling sequence 0-50% 24V |
| → | Water cooling secondary sequence | Cooling sequence 50-100% 24V |
| → | Water heating primary sequence | Heating sequence 0-50% 24V |
| → | Water heating secondary sequence | Heating sequence 50-100% 24V |
| → | Light Control | Lighting output on/off signal |
| Analog output 1,2,3 (19,16,13) | | Description |
| → | Not used | No signal on the output |
| → | Water cooling | 0-10V for a cooling demand |
| → | Water heating | 0-10V for a heating demand |
| → | Water change over 2 pipe | 0-10V for cooling/heating demand |
| → | Water change over 4 pipe | For 6-way valve, 0-5V=cooling, 5-10V=heating |
| → | Water cooling primary sequence | Cooling sequence 0-50% 0-10V |
| → | Water cooling secondary sequence | Cooling sequence 50-100% 0-10V |
| → | Water heating primary sequence | Heating sequence 0-50% 0-10V |
| → | Water heating secondary sequence | Heating sequence 50-100% 0-10V |
| → | ECOPulse | Control signal for integrated damper at 3 different operating modes |
| → | 2step | Control signal for integrated damper at 3 different operating modes |
| → | Variable | Control signal for integrated damper at 3 different operating modes |
| → | ADAPT analog extract air | Calculated 0-10V signal for extract air (ADAPT Damper) |
| → | ADAPT slave supply air | PARASOL Zenith VAV slave (control signal to internal damper) |
| → | Light Control | Lighting output control signal |

Regulator inputs

The inputs on the regulator




Inputs' standard settings

| Input configuration | |
|---------------------|------------------------|
| Input 1 usage | Not used ▼ |
| Input 3 usage | Not used ▼ |
| Input 4 usage | Not used ▼ |
| Occ. mode | Use occupancy sensor ▼ |

The inputs can be switched with SWICCT for alternative functions, for example, the use of keycard switches and window contacts

| Input 1 usage | | Description |
|---------------|-------------------------|--|
| → | Not used | Not used |
| → | Room Temperature | External temperature sensor is used |
| → | Change over temperature | Ext. Temp sensor for change-over is used |
| → | Temperature (read only) | Only temp. reading, no regulation |
| → | Window contact NO | Window contact normally open |
| → | Window contact NC | Window contact normally closed |
| Input 3 usage | | |
| → | Not used | Not used |
| → | CO2 0-10V | CO2 sensor with 0-10 V control range |
| → | CO2 2-10V | CO2 sensor with 2-10 V control range |
| Input 4 usage | | |
| → | Not used | Not used |
| → | Keycard switch NO | Keycard switch normally open |
| → | Keycard switch NC | Keycard switch normally closed |
| → | Window contact NO | Window contact normally open |
| → | Window contact NC | Window contact normally closed |
| → | Change-over contact NO | Change-over contact normally open |
| → | Change-over contact NC | Change-over contact normally closed |
| Occ mode | | |
| | Use occupancy sensor | Detect occupancy/no occupancy |
| | Always occupied | Force to occupancy mode |
| | Always unoccupied | Force on in unoccupied mode |

Regulator's Modbus connections



The master circuit (22, 23) is used for communication between PARASOL Zenith VAV master units and communication from the master unit up to the superordinate system, for example, SuperWISE.

The slave circuit (24, 25) is used for communication between slave units PARASOL Zenith VAV and to connect the sensor module, pressure sensor, VOC sensor, etc.

Note that 22 and 23 are parallel (same function), and 24 and 25 are parallel. Important to distinguish between the pairs 22/23 and 24/25.

The order of the connected units on each circuit is not important, however it is more important to avoid so-called Stubs and build just one circuit instead.

4x RS485, modular RJ12 6/6

22 & 23 parallel, master circuit


24 & 25 parallel, slave circuit

Systems Engineering

Duct system

Remember:

- PARASOL Zenith VAV measures the pressure in each unit and can therefore manage the occupancy flow in a good way as long as there is sufficient duct pressure available, see figure
- The built-in damper generates very little noise compared with traditional commissioning damper and in many cases a sound attenuator in the room can therefore be excluded. However, beware of other sounds such as crosstalk and noise from e.g. zone dampers further back in the system.
- By selecting the unoccupied flow and maximum occupancy flow in a smart way in the software you also compensate for the duct pressure drop and control measurement is easier, see page 20-21.
- The software manages the flows, but beware of the noise and effects, see page 20-21.
- However, traditional commissioning dampers may be required for duct lengths and duct pressure drop outside the recommended ranges. This is easily checked by using IC Design by entering the actual duct pressure on the actual product.




Traditional system design with pressure controlled units and zone dampers that maintain a constant pressure in each zone. In a small installation, a good unit can possibly maintain a sufficiently constant pressure.

Duct system

Minimum and maximum flows from IC Design limited by the available pressure and nozzle configuration selected for an PARASOL Zenith VAV 1200 HF LMLM.

Min. occupancy flow is selectable in IC Design and here is set to 15 l/s.


For an accepted pressure drop in the duct system of 1 Pa/m, the following can be used:



In SWICCT or by configuring PARASOL Zenith VAV in ProWISE limits can also be set for unoccupied and occupancy max flow (note the product's absolute min and max from the previous figure which are controlled by the selected nozzle setting!)

By letting the most exposed product in this way be the design unit for the current duct section and taking this into account at an early stage, you do not use a balancing damper before each product and can thus save both available pressure and money on unnecessary commissioning dampers, which in addition also risk creating noise.

Of course, the pressure fluctuations in a duct system can be so large that the traditional commissioning damper is still required, in all probability a damper in front of each product is not necessary as it should be enough to lower the pressure in some of the duct system and then apply the above.



Duct system

In the case above the design unit is of 110 Pa instead of as in the previous example, 80 Pa, and now we see that the first unit in the duct branch will have about 31 l/s and a pressure of 134 Pa. This flow gives a slightly louder noise from the nozzles, but as before lowering the maximum flow in software gives partly the same measured flow in each room, but also an improved noise level on the most exposed PARASOL Zenith VAV.

Setting the max air flow to 27 l/s gives 29 dB, as well as the maximum flow is the same for all units which may be desirable for commissioning/control measurement. Check, however, so that the cooling/heating output to the room is still OK.


1.

| | |
|-----------------------------|------|
| Duct pressure, Pa | 134 |
| Sound pressure level, Lp(A) | 31 |
| Min. l/s | 5.7 |
| Occupancy l/s | 15 |
| Max. l/s | 31.6 |

| Design unit. | |
|-----------------------------|------|
| Duct pressure, Pa | 110 |
| Sound pressure level, Lp(A) | 28 |
| Min. l/s | 5.1 |
| Occupancy l/s | 15 |
| Max. l/s | 28.7 |

| | |
|-----------------------------|------|
| Duct pressure, Pa | 98 |
| Sound pressure level, Lp(A) | 27 |
| Min. l/s | 4.8 |
| Occupancy l/s | 15 |
| Max. l/s | 27.0 |

Design instance 110 Pa gives 28 dBA and 28.7 l/s in the maximum position. The most vulnerable unit in this case will have 134 Pa, 31 dBA and 31.6 l/s.



2.

| | |
|-----------------------------|-----|
| Duct pressure, Pa | 134 |
| Sound pressure level, Lp(A) | 29 |
| Min. l/s | 5.7 |
| Occupancy l/s | 15 |
| Max. l/s | 27 |

| | |
|-----------------------------|-----|
| Duct pressure, Pa | 110 |
| Sound pressure level, Lp(A) | 27 |
| Min. l/s | 5.1 |
| Occupancy l/s | 15 |
| Max. l/s | 27 |

| | |
|-----------------------------|------|
| Duct pressure, Pa | 98 |
| Sound pressure level, Lp(A) | 27 |
| Min. l/s | 4.8 |
| Occupancy l/s | 15 |
| Max. l/s | 27.0 |

By balancing the flows as before in software, in this case you can also rectify the rather high noise level. However, note the slightly lower effects produced.


2-step optimisation in WISE gen.1

1. Zone and room optimisation

2-step optimisation is a further development of today's optimisation performed by SuperWISE. All zone dampers continuously check the damper position on products that are on the level below the zone damper and are connected via Modbus communications.

It is always the room damper with the greatest degree of opening that controls the zone damper for optimisation.

During normal operation, the most open room damper as standard should be between 70-90% open. If the most open room damper is open more than 90% the air flow in the zone is not sufficient. In this case, the zone damper will be opened until the most open room damper is open to less than 90%. If the most open room damper is open less than 70% the air flow in the zone is too high. In this case, the zone damper will be closed until the most open room damper is open to more than 70%.




If a room damper is outside the limit 70-90% open, the zone damper is adjusted by being opened/closed.

2-step optimisation in WISE gen.1

2. Units and zone optimisation


SuperWISE continuously controls the position of the zone damper, according to the same principle previously described for room dampers.

The unit's pressure setpoint is increased/decreased depending on the needs of the zones. The router simulates a zone damper and always shows the most open room product for supply air and extract air that is connected via Modbus to the router. If only the supply or extract air is used only this appears




If a zone damper is outside the limit 70-90% open, the unit's pressure setpoint is increased/decreased until the zone damper is within the limits


Master/Slaves




Display in Super Wise



The SuperWISE display illustrates a room with 6 x PARASOL Zenith VAV for supply air and 2 x ADAPT Damper extract air.
 The supply air is distributed on one master and five slaves, and as previously noted the slaves are not shown in this view, the master shows the room's supply air flow.



If you wish to see the supply air flow in more detail, highlight PARASOL Zenith VAV in the menu tree and the flow for all 5 underlying slaves will be shown.



| Air flow actual values | |
|---|-----------|
| Total supply air flow to the room | 230.5 l/s |
| Calculated setpoint for the total supply air flow | 229.4 l/s |
| Current pressure, Master | 31.0 Pa |
| Supply air flow slave 1 | 46.4 l/s |
| Supply air flow slave 2 | 46.5 l/s |
| Supply air flow slave 3 | 45.8 l/s |
| Supply air flow slave 4 | 24.4 l/s |
| Supply air flow slave 5 | 22.9 l/s |

IC Design

At the present time sizing and hardware configuration is performed in IC Design

Contact Helpdesk

Telephone: +46 512 - 78 24 44

Weekdays between 08:00-11:30, 12:30-15:00

E-mail: helpdesk.teknik@swegon.se

Heat with PARASOL Zenith VAV

| | | |
|-----------------------------|-------------------------------------|---------|
| Heat type | Radiator | |
| Cold draft protection level | 3000 | % * 100 |
| Cold draft protection stop | 5000 | % * 100 |
| Cold draft protection UnOcc | <input checked="" type="checkbox"/> | |

Display from SWICCT and part of the "service mode" tab

1. **Protection level:** The amount the heating actuator is permitted to be open for cold draught protection. Default 30%, i.e. even if there is no heating load the 30% signal is sent out on the heat output.
2. **Protection stop:** At what cooling signal the cold draught protection should stop. Default 50%, i.e. when the cooling signal is 50% or more the cold draught protection is not permitted and no signal is sent out on the heating output.
3. **UnOcc:** Checked box means that the cold draught protection is active even when no one is in the room.

Heat type Radiator

In cases where the room is heated with PARASOL Zenith VAV, an increased air flow will result in an increased heat output being supplied to the room, the increased air volume "carries" out the water heat.

However, if the heat comes from an external radiator or a floor heating system, an increased air flow involves exactly the opposite effect, it only adds cold air to the room.

In order to avoid this you can choose radiator in the software as heat-type, which means that the boost function is blocked for a heating load.

Heat type Water actuator means the heat is controlled as usual with PARASOL Zenith VAVs heating coil and the actuator there.

Cold draught protection

Cold draught protection, allows the PARASOL Zenith VAV to send out heat signal even though there is a cooling load.

This is to be able to counteract cold draughts from such an inferior window with a radiator.

Cold draught protection is only run together with the choice Heat type radiator.

Note that the cold draught protection means that both cooling and heating actuators are energized at the same time, which increases the load on the output and transformer with 6 VA / actuator.

Sensor module

The sensor module is ideally placed on the wall for temperature measurement, if located in the faceplate there is a risk it measures a too high temperature.


Alternatively, an external temperature sensor can be used.

In a conference room you can have sensor modules in all faceplates to indicate occupancy and an extra sensor module on the wall for temperature measurements and/or setpoint setting.

Air quality sensor

General

- The VOC sensor (Volatile Organic Compound), measures the content of emissions/impurities in the unit % VOC.
- When an occupant emits CO₂, this creates a proportional amount of emissions/impurities which are measurable by the VOC sensor.
- For an approximate translation of the % VOC to CO₂ content, see diagram.
- The sensors are concealed behind the faceplate on the PARASOL Zenith VAV and thus sit in the current of induced room air.
- The VOC sensor generally does not react to a specific substance but a variety of substances.
- The VOC sensor is Modbus connected and can be connected to PARASOL Zenith VAV master or slave.
- The CO₂ sensor is connected to an analogue input and must be connected to PARASOL Zenith VAV master.
- Both can be factory fitted behind the faceplate.



Data entry in SWICCT:

- The PPM values are similar as for a CO₂ sensor, and are then recalculated to a correct output signal corresponding to the adjoining diagram.
- The values set in the adjoining figure signify that the PARASOL Zenith VAV has started to release more air at the equivalent of 600 ppm in the room, and continues variably up to 1200 ppm (max flow)
- VOC use Auto means that the control automatically detects whether the sensor is connected. OFF mode is used to disable already read sensors.
- Input 3 usage is only used for CO₂ sensors and you specify here whether it is a 0-10 V or 2-10 V sensor.
- PPM CO₂ / volt can also be set for the CO₂ sensor in instances when sensors other than standard are used.
- See functional description air on page 17.
- More info about VOC and substances: Product sheet CAC on swegon.se.
- Regulation according to the air quality sensor also occurs in unoccupied mode (can be adjusted).

| CO2/VOC | | |
|-----------------------|-----------|-----|
| VOC use | Auto | ▼ |
| CO2/VOC min set value | 700 | ppm |
| CO2/VOC max set value | 1000 | ppm |
| Input 3 usage | CO2 2-10V | ▼ |
| CO2/Volt (sensor) | 200 | ppm |


CO₂ or VOC?

Carbon dioxide CO₂ is in itself harmless, but is easy to measure and provides a good indication to the occupancy load in a building. However, a CO₂ sensor does not react to emissions from e.g. building materials or strong odours such as perfume, unlike a VOC sensor.

Change –over system

2-pipe system with cooling in the summer and heating in the winter

- 2-pipe system with cooling water in the summer and heating water in the winter
- GT_1 is placed where heating or cooling water always circulates
- Summer: If the room temperature T_2 is higher than the water temperature T_1 , the valve opens when cooling is required.
- Winter: If the room temperature T_2 is lower than the water temperature T_1 , the valve opens when heating is required.
- GT_1 is connected to the regulator as an external temperature sensor
- In SWICCT or SuperWISE (see below) you tell the regulator that the sensor is to be used for the Change-Over function.
- GT_2 is the temperature sensor which is located in the PARASOL Zenith VAV's sensor module
- Note: The valve actuator must be connected to the regulator's cooling output.



In SWICCT you make the change in one of these places, either under “Input configuration” or “External temperature sensor use”. Irrespective of where you make the change, the other changes automatically.

Input configuration

Input 1 usage

Input 3 usage

Input 4 usage

Occ. mode

Change over temperature

Not used

Room temperature

Change over temperature

Temperature (read only)

Window contact NO

Window contact NC

External temperature sensor use

Change over temperature

Not used

Room temperature

Change over temperature

Temperature (read only)

Window contact NO

Window contact NC

The input's function can also be changed via SuperWISE:

Other parameters

Analogue input 1

Analogue input 2

Analogue input 3

Extern temp

Select value:

Non active

Non active

Extern temp. room

Extern temp. ChOv

Extern temp. reading

Window contact NO

Window contact NC

Cancel

OK

Control of the lighting

Use of analogue output to switch an external relay

The regulator's analogue outputs no. 13 or 19 (see page xx) can be used to switch an external relay for lighting. The output is really intended to control actuators or internal dampers, but when 10V is fed on the output for occupancy (assuming that the output is configured 2-step, i.e. 0% output signal for unoccupied and 100% output for occupancy) lighting can also be managed for example by means of an external relay.

Note that this is an alternative use of the output, which means no own intelligence for just lighting control is connected to this.

For more information and assistance with connections contact the factory.

Start-up and Zero point calibration

During initial start-up after a power failure and for zero point calibration, the internal damper will open to fully open to read the current duct pressure in this position.

The damper is open for a few minutes and then closes and then start normal regulation of the air flow.

For zero point calibration, close the damper, the pressure sensor actual value is reset and then the start-up procedure is performed as above.

Calibration is activated via SuperWISE, SWICCT or via Modbus.

Two-stage cooling/two stage heating

The function two-step cooling means that both actuator outputs are used for cooling, this in order to supplement with extra cooling on output number two when the cooling on output no one is not sufficient.

For 0-50% of the cooling load, 100% is put on one output and for a 50-100% cooling load 100% output signal is put on both outputs.


Note that in this case the voltage is on both outputs simultaneously, which can affect the choice of transformer.

The above applies in the same way in two-step heating.


Also note that only cooling or heating can be regulated according to the two-step principle when the same outputs are used.

The corresponding settings can be made on the analogue outputs for e.g. 0-10V actuators

| Output configuration | |
|----------------------|------------------------------------|
| Digital output 1(21) | Water cooling primary sequence ▼ |
| Analog output 1(19) | Not used ▼ |
| Digital output 2(18) | Water cooling secondary sequence ▼ |
| Analog output 2(16) | Not used ▼ |
| Digital output 3(15) | Not used ▼ |
| Analog output 3(13) | Variable ▼ |



| Output configuration | |
|----------------------|------------------------------------|
| Digital output 1(21) | Water heating primary sequence ▼ |
| Analog output 1(19) | Not used ▼ |
| Digital output 2(18) | Water heating secondary sequence ▼ |
| Analog output 2(16) | Not used ▼ |
| Digital output 3(15) | Not used ▼ |
| Analog output 3(13) | Variable ▼ |



Modbus register 1.57

| Coil | | | | | | |
|--------------|---|-----|-----|------|----------|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 0x0001 | Emergency | 0 | 1 | 0 | | Emergency mode |
| 0x0002 | BOOT (first write parameters) | 0 | 1 | 0 | | BOOT (first write parameters) |
| 0x0003 | Force parameter write | 0 | 1 | 0 | | Force parameter write |
| 0x0004 | Clear all alarms | 0 | 1 | 0 | | Clear all alarms |
| 0x0005 | Holiday | 0 | 1 | 0 | | Holiday mode |
| 0x0006 | SNC | 0 | 1 | 0 | | Summer night cooling mode |
| 0x0007 | Zero calibration demand to pressure sensor | 0 | 1 | 0 | | Zero calibration |
| 0x0008 | Man valve test | 0 | 1 | 0 | | Manual valve test |
| 0x0009 | Man vent boost | 0 | 1 | 0 | | Manual ventilation boost |
| 0x0010 | Reset temperature offset. | 0 | 1 | 0 | | Reset temperature offset |
| 0x0011 | Water actuator STOP | 0 | 1 | 0 | | Water actuator STOP |
| 0x0012 | Air quality active UnOcc | 0 | 1 | 0 | | Air quality regulation active in unoccupancy mode |
| 0x0013 | Group occupancy | 0 | 1 | 0 | | Occupancy from group |
| 0x0014 | Cold draft protection active in unoccupancy | 0 | 1 | 0 | | Cold draft protection active in unoccupancy mode |
| 0x0015 | Slave bus reset | 0 | 1 | 0 | | Slave bus reset |
| 0x0016 | Reset VOC reset counter | 0 | 1 | 0 | | Reset VOC reset counter |
| Input status | | | | | | |
| ID | Name | Min | Max | Init | Settings | Description |
| 1x0001 | AC power supply. | 0 | 1 | 0 | | AC power supply |
| 1x0002 | Discrete air hatch open (fixed) | 0 | 1 | 0 | | Discrete air hatch open (fixed) |
| 1x0003 | Discrete air hatch open (pulsing) | 0 | 1 | 0 | | Discrete air hatch open (pulsing) |
| 1x0004 | Discrete air hatch Parasol slave | 0 | 1 | 0 | | Discrete air hatch Parasol slave |
| 1x0005 | Air flow forced | 0 | 1 | 0 | | Air flow forced |
| 1x0006 | Vent boost active | 0 | 1 | 0 | | Ventilation boost active |
| 1x0007 | Valve exercise active | 0 | 1 | 0 | | Valve exercise active |
| 1x0008 | Condensation | 0 | 1 | 0 | | Condensation state |
| 1x0009 | Digital in (IN4) | 0 | 1 | 0 | | Digital in (IN4) state |
| 1x0010 | Window open | 0 | 1 | 0 | | Window open |
| 1x0011 | Occupancy incl delays | 0 | 1 | 0 | | Occupancy including delays |
| 1x0012 | Occupancy SM 1 | 0 | 1 | 0 | | Occupancy sensor module 1 |
| 1x0013 | Occupancy SM 2 | 0 | 1 | 0 | | Occupancy sensor module 2 |
| 1x0014 | Occupancy SM 3 | 0 | 1 | 0 | | Occupancy sensor module 3 |
| 1x0015 | Occupancy SM 4 | 0 | 1 | 0 | | Occupancy sensor module 4 |
| 1x0016 | Occupancy SM 5 | 0 | 1 | 0 | | Occupancy sensor module 5 |
| 1x0017 | Occupancy SM 6 | 0 | 1 | 0 | | Occupancy sensor module 6 |
| 1x0018 | Occupancy SM 7 | 0 | 1 | 0 | | Occupancy sensor module 7 |
| 1x0019 | Occupancy SM 8 | 0 | 1 | 0 | | Occupancy sensor module 8 |
| 1x0020 | Occupancy SM 9 | 0 | 1 | 0 | | Occupancy sensor module 9 |
| 1x0021 | Occupancy SM 10 | 0 | 1 | 0 | | Occupancy sensor module 10 |
| 1x0022 | Change over Heat present | 0 | 1 | 0 | | Change over hot water present |
| 1x0023 | Change over Cool present | 0 | 1 | 0 | | Change over cold water present |
| 1x0024 | Digital out 1 status | 0 | 1 | 0 | | Digital out 1 status |
| 1x0025 | Digital out 2 status | 0 | 1 | 0 | | Digital out 2 status |
| 1x0026 | Digital out 3 status | 0 | 1 | 0 | | Digital out 3 status |

| Input status | | | | | | |
|--------------|---------------------------------|-----|-----|------|----------|------------------------------------|
| ID | Name | Min | Max | Init | Settings | Description |
| 1x1000 | Sum alarm for functional alarms | 0 | 1 | 0 | | Sum alarm for functional alarms |
| 1x1001 | Sum alarm for comfort alarms | 0 | 1 | 0 | | Sum alarm for comfort alarms |
| 1x1002 | Supply voltage low | 0 | 1 | 0 | | Supply voltage low |
| 1x1003 | Supply voltage critical low | 0 | 1 | 0 | | Supply voltage critical low |
| 1x1004 | Ext temp missing | 0 | 1 | 0 | | External temperature missing |
| 1x1005 | Ext temp error | 0 | 1 | 0 | | External temperature error |
| 1x1006 | Condensation sensor error | 0 | 1 | 0 | | Condensation sensor error |
| 1x1007 | SM temp sensor error | 0 | 1 | 0 | | Sensor module temperature error |
| 1x1008 | SM button error | 0 | 1 | 0 | | Sensor module button error |
| 1x1009 | CO2 sensor missing | 0 | 1 | 0 | | CO2 sensor missing |
| 1x1010 | VOC Error | 0 | 1 | 0 | | VOC Error |
| 1x1011 | Low pressure | 0 | 1 | 0 | | Low pressure |
| 1x1012 | -- Not used -- Alarm 11 | 0 | 1 | 0 | | -- Not used -- Alarm 11 |
| 1x1013 | -- Not used -- Alarm 12 | 0 | 1 | 0 | | -- Not used -- Alarm 12 |
| 1x1014 | -- Not used -- Alarm 13 | 0 | 1 | 0 | | -- Not used -- Alarm 13 |
| 1x1015 | -- Not used -- Alarm 14 | 0 | 1 | 0 | | -- Not used -- Alarm 14 |
| 1x1016 | -- Not used -- Alarm 15 | 0 | 1 | 0 | | -- Not used -- Alarm 15 |
| 1x1017 | -- Not used -- Alarm 16 | 0 | 1 | 0 | | -- Not used -- Alarm 16 |
| 1x1018 | SM comm error | 0 | 1 | 0 | | Sensor module communication error |
| 1x1019 | Slave comm error | 0 | 1 | 0 | | Slave communication error |
| 1x1020 | Pressure sensor comm error | 0 | 1 | 0 | | Pressure sensor comm error |
| 1x1021 | VOC sensor comm error | 0 | 1 | 0 | | VOC sensor communication error |
| 1x1022 | No master request (slave) | 0 | 1 | 0 | | No master request (slave) |
| 1x1023 | Slave incompatible version | 0 | 1 | 0 | | Slave incompatible version |
| 1x1024 | -- Not used -- Alarm 23 | 0 | 1 | 0 | | -- Not used -- Alarm 23 |
| 1x1025 | -- Not used -- Alarm 24 | 0 | 1 | 0 | | -- Not used -- Alarm 24 |
| 1x1026 | Heating comfort alarm | 0 | 1 | 0 | | Heating comfort alarm |
| 1x1027 | Cooling comfort alarm | 0 | 1 | 0 | | Cooling comfort alarm |
| 1x1028 | Temp. Set point overlap alarm | 0 | 1 | 0 | | Temperature setpoint overlap alarm |
| 1x1029 | Air quality comfort alarm | 0 | 1 | 0 | | Air quality comfort alarm |
| 1x1030 | Condensation | 0 | 1 | 0 | | Condensation |
| 1x1031 | -- Not used -- Alarm 30 | 0 | 1 | 0 | | -- Not used -- Alarm 30 |
| 1x1032 | -- Not used -- Alarm 31 | 0 | 1 | 0 | | -- Not used -- Alarm 31 |
| 1x1033 | -- Not used -- Alarm 32 | 0 | 1 | 0 | | -- Not used -- Alarm 32 |
| 1x1034 | 24 V Out 1 overload error | 0 | 1 | 0 | | 24 V Output 1 overload error |
| 1x1035 | 24 V Out 2 overload error | 0 | 1 | 0 | | 24 V Output 2 overload error |
| 1x1036 | 24 V Out 3 overload error | 0 | 1 | 0 | | 24 V Output 3 overload error |
| 1x1037 | -- Not used -- Alarm 36 | 0 | 1 | 0 | | -- Not used -- Alarm 36 |
| 1x1038 | -- Not used -- Alarm 37 | 0 | 1 | 0 | | -- Not used -- Alarm 37 |
| 1x1039 | -- Not used -- Alarm 38 | 0 | 1 | 0 | | -- Not used -- Alarm 38 |
| 1x1038 | -- Not used -- Alarm 37 | | | | | -- Not used -- Alarm 37 |
| 1x1039 | -- Not used -- Alarm 38 | | | | | -- Not used -- Alarm 38 |
| 1x1040 | -- Not used -- Alarm 39 | 0 | 1 | 0 | | -- Not used -- Alarm 39 |
| 1x1041 | -- Not used -- Alarm 40 | 0 | 1 | 0 | | -- Not used -- Alarm 40 |
| 1x1042 | Slave input sum alarm | 0 | 1 | 0 | | Slave input sum alarm |
| 1x1043 | Slave output sum alarm | 0 | 1 | 0 | | Slave output sum alarm |
| 1x1044 | -- Not used -- Alarm 43 | 0 | 1 | 0 | | -- Not used -- Alarm 43 |
| 1x1045 | -- Not used -- Alarm 44 | 0 | 1 | 0 | | -- Not used -- Alarm 44 |
| 1x1046 | -- Not used -- Alarm 45 | 0 | 1 | 0 | | -- Not used -- Alarm 45 |
| 1x1047 | -- Not used -- Alarm 46 | 0 | 1 | 0 | | -- Not used -- Alarm 46 |
| 1x1048 | -- Not used -- Alarm 47 | 0 | 1 | 0 | | -- Not used -- Alarm 47 |
| 1x1049 | -- Not used -- Alarm 48 | 0 | 1 | 0 | | -- Not used -- Alarm 48 |

| Input status | | | | | | |
|----------------|-------------------------------------|--------|-------|------|--|--|
| ID | Name | Min | Max | Init | Settings | Description |
| 1x1050 | -- Not used -- Alarm 49 | 0 | 1 | 0 | | -- Not used -- Alarm 49 |
| 1x1051 | -- Not used -- Alarm 50 | 0 | 1 | 0 | | -- Not used -- Alarm 50 |
| 1x1052 | -- Not used -- Alarm 51 | 0 | 1 | 0 | | -- Not used -- Alarm 51 |
| 1x1053 | -- Not used -- Alarm 52 | 0 | 1 | 0 | | -- Not used -- Alarm 52 |
| 1x1054 | -- Not used -- Alarm 53 | 0 | 1 | 0 | | -- Not used -- Alarm 53 |
| 1x1055 | -- Not used -- Alarm 54 | 0 | 1 | 0 | | -- Not used -- Alarm 54 |
| 1x1056 | -- Not used -- Alarm 55 | 0 | 1 | 0 | | -- Not used -- Alarm 55 |
| 1x1057 | -- Not used -- Alarm 56 | 0 | 1 | 0 | | -- Not used -- Alarm 56 |
| 1x1058 | -- Not used -- Alarm 57 | 0 | 1 | 0 | | -- Not used -- Alarm 57 |
| 1x1059 | -- Not used -- Alarm 58 | 0 | 1 | 0 | | -- Not used -- Alarm 58 |
| 1x1060 | -- Not used -- Alarm 59 | 0 | 1 | 0 | | -- Not used -- Alarm 59 |
| 1x1061 | -- Not used -- Alarm 60 | 0 | 1 | 0 | | -- Not used -- Alarm 60 |
| 1x1062 | -- Not used -- Alarm 61 | 0 | 1 | 0 | | -- Not used -- Alarm 61 |
| 1x1063 | -- Not used -- Alarm 62 | 0 | 1 | 0 | | -- Not used -- Alarm 62 |
| 1x1064 | -- Not used -- Alarm 63 | 0 | 1 | 0 | | -- Not used -- Alarm 63 |
| 1x1065 | -- Not used -- Alarm 64 | 0 | 1 | 0 | | -- Not used -- Alarm 64 |
| Input register | | | | | | |
| ID | Name | Min | Max | Init | Settings | Description |
| 3x0001 | Component Name ID | 0 | 32767 | 19 | | Component name ID |
| 3x0002 | Bootloader revision | 0 | 32767 | 0 | | Bootloader revision number |
| 3x0003 | SW revision | 0 | 32767 | 157 | | Software revision number |
| 3x0004 | HW revision | 0 | 15 | 0 | | Hardware revision number |
| 3x0005 | Serial number 1 | -32768 | 32767 | 0 | | Serial number |
| 3x0006 | Serial number 2 | -32768 | 32767 | 0 | | Serial number |
| 3x0007 | Serial number 3 | -32768 | 32767 | 0 | | Serial number |
| 3x0008 | Serial number 4 | -32768 | 32767 | 0 | | Serial number |
| 3x0009 | Serial number 5 | -32768 | 32767 | 0 | | Serial number |
| 3x0010 | Serial number 6 | -32768 | 32767 | 0 | | Serial number |
| 3x0011 | Serial number 7 | -32768 | 32767 | 0 | | Serial number |
| 3x0012 | Serial number 8 | -32768 | 32767 | 0 | | Serial number |
| 3x0018 | Application id | 0 | 32767 | 15 | | Application ID |
| 3x0020 | Number of connected sensor modules. | 0 | 10 | 0 | | Number of connected sensor modules. |
| 3x0021 | Number of connected slaves | 0 | 9 | 0 | | Number of connected slaves |
| 3x0022 | Occupancy SM (bit code) | 0 | 1023 | 0 | | Occupancy sensor module in bit code |
| 3x0023 | Output current | 0 | 10000 | 0 | | Actual output current |
| 3x0024 | Pressure | -4000 | 25000 | 0 | | Actual pressure value |
| 3x0025 | CO2 ppm | 0 | 2000 | 0 | | Actual CO2 ppm value |
| 3x0026 | VOC ppm | 0 | 2000 | 0 | | Actual VOC ppm value |
| 3x0027 | RH % | 0 | 10000 | 0 | | Actual Relative humidity value (%) |
| 3x0028 | Temperature from VOC sensor | -5000 | 8000 | 0 | | Actual temperature value from VOC sensor |
| 3x0029 | Input status mirror | -32768 | 32767 | 0 | | Input status mirror |
| 3x0030 | Input status mirror | -32768 | 32767 | 0 | | Input status mirror |
| Input register | | | | | | |
| ID | Name | Min | Max | Init | Settings | Description |
| 3x0032 | Device state | 0 | 11 | 0 | "0=Not initiated yet, 1=Device is starting up, 2=Occupied, 3=Unoccupied, 4=Holiday, 5=Valve exercise, 6=Summer night cool, 7=Commissioning, 8=Slave, 9=Emergency, 10=Stop state (used when an alarm forces the regulator to stop), 11=Open Window" | Actual device state |

| Input register | | | | | | |
|----------------|---------------------------------------|--------|-------|------|----------|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 3x0033 | Actual mean airflow. | 0 | 32767 | 0 | | Actual mean airflow value |
| 3x0034 | Temp Ext | -5000 | 8000 | 0 | | Actual temperature value external |
| 3x0035 | Condensation | 0 | 1 | 0 | | Condensation state |
| 3x0036 | Alarm 1-16 | -32768 | 32767 | 0 | | Alarm 1-16 |
| 3x0037 | Alarm 17-32 | -32768 | 32767 | 0 | | Alarm 17-32 |
| 3x0038 | Alarm 33-48 | -32768 | 32767 | 0 | | Alarm 33-48 |
| 3x0039 | Alarm 49-64 | -32768 | 32767 | 0 | | Alarm 49-64 |
| 3x0040 | Slave id for first Slave active alarm | 0 | 10 | 0 | | Slave id for first Slave active alarm |
| 3x0041 | SM id for first SM active alarm | 0 | 10 | 0 | | Sensor module id for first sensor module active alarm |
| 3x0042 | Alarm 1-16 history | -32768 | 32767 | 0 | | Alarm 1-16 history |
| 3x0043 | Alarm 17-32 history | -32768 | 32767 | 0 | | Alarm 17-32 history |
| 3x0044 | Alarm 33-48 history | -32768 | 32767 | 0 | | Alarm 33-48 history |
| 3x0045 | Alarm 49-64 history | -32768 | 32767 | 0 | | Alarm 49-64 history |
| 3x0046 | Analog input (IN3) | 0 | 100 | 0 | | Actual value analog input (IN3) |
| 3x0047 | Digital output 1. | 0 | 10000 | 0 | | Digital output 1 state |
| 3x0048 | Digital output 2. | 0 | 10000 | 0 | | Digital output 2 state |
| 3x0049 | Digital output 3. | 0 | 10000 | 0 | | Digital output 3 state |
| 3x0050 | Analogue output 1. | 0 | 10000 | 0 | | Analog output 1 value |
| 3x0051 | Analogue output 2. | 0 | 10000 | 0 | | Analog output 2 value |
| 3x0052 | Analogue output 3. | 0 | 10000 | 0 | | Analog output 3 value |
| 3x0053 | Room temp | -5000 | 8000 | 2000 | | Actual room temperature |
| 3x0054 | Room temp set point | -5000 | 8000 | 2200 | | Actual room temperature setpoint |
| 3x0055 | Temp Low limit | 0 | 10000 | 0 | | Temperature low limit |
| 3x0056 | Temp Hi limit | 0 | 10000 | 0 | | Temperature high limit |
| 3x0057 | Temp load | -10000 | 10000 | 0 | | Actual temperature load |
| 3x0058 | Temp set point offset Occ | -1200 | 1200 | 0 | | Temperature setpoint offset occupancy mode |
| 3x0059 | Sensor module set point offset | -3 | 3 | 0 | | Actual temperature offset from sensor module |
| 3x0060 | Temp Slave controller 1 | -5000 | 8000 | 0 | | Actual temperature slave controller 1 |
| 3x0061 | Temp Slave controller 2 | -5000 | 8000 | 0 | | Actual temperature slave controller 2 |
| 3x0062 | Temp Slave controller 3 | -5000 | 8000 | 0 | | Actual temperature slave controller 3 |
| 3x0063 | Temp Slave controller 4 | -5000 | 8000 | 0 | | Actual temperature slave controller 4 |
| 3x0064 | Temp Slave controller 5 | -5000 | 8000 | 0 | | Actual temperature slave controller 5 |
| 3x0065 | Temp Slave controller 6 | -5000 | 8000 | 0 | | Actual temperature slave controller 6 |
| 3x0066 | Temp Slave controller 7 | -5000 | 8000 | 0 | | Actual temperature slave controller 7 |
| 3x0067 | Temp Slave controller 8 | -5000 | 8000 | 0 | | Actual temperature slave controller 8 |
| 3x0068 | Temp Slave controller 9 | -5000 | 8000 | 0 | | Actual temperature slave controller 9 |
| 3x0069 | Temp SM1 | -5000 | 8000 | 0 | | Actual temperature sensor module 1 |
| 3x0070 | Temp SM2 | -5000 | 8000 | 0 | | Actual temperature sensor module 2 |
| 3x0071 | Temp SM3 | -5000 | 8000 | 0 | | Actual temperature sensor module 3 |
| 3x0072 | Temp SM4 | -5000 | 8000 | 0 | | Actual temperature sensor module 4 |
| 3x0073 | Temp SM5 | -5000 | 8000 | 0 | | Actual temperature sensor module 5 |
| 3x0074 | Temp SM6 | -5000 | 8000 | 0 | | Actual temperature sensor module 6 |
| 3x0075 | Temp SM7 | -5000 | 8000 | 0 | | Actual temperature sensor module 7 |
| 3x0076 | Temp SM8 | -5000 | 8000 | 0 | | Actual temperature sensor module 8 |
| 3x0077 | Temp SM9 | -5000 | 8000 | 0 | | Actual temperature sensor module 9 |
| 3x0078 | Temp SM10 | -5000 | 8000 | 0 | | Actual temperature sensor module 10 |
| 3x0079 | Air flow load | 0 | 10000 | 0 | | Actual airflow load signal |
| 3x0080 | Air flow set point | 0 | 32767 | 0 | | Actual airflow setpoint |
| 3x0081 | Air flow moving average | 0 | 32767 | 0 | | Air flow moving average |
| 3x0082 | Air quality load | 0 | 10000 | 0 | | Actual air quality load signal |
| 3x0083 | Air quality | 0 | 2000 | 0 | | Actual air quality |
| 3x0084 | Damper signal | 0 | 10000 | 0 | | Damper signal |
| 3x0085 | Airflow control signal | 0 | 10000 | 0 | | Airflow control signal |

| Input register | | | | | | |
|----------------|-------------------------------------|--------|-------|-------|----------|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 3x0086 | Air flow Slave controller 1 | 0 | 32767 | 0 | | Actual airflow slave controller 1 |
| 3x0087 | Air flow Slave controller 2 | 0 | 32767 | 0 | | Actual airflow slave controller 2 |
| 3x0088 | Air flow Slave controller 3 | 0 | 32767 | 0 | | Actual airflow slave controller 3 |
| 3x0089 | Air flow Slave controller 4 | 0 | 32767 | 0 | | Actual airflow slave controller 4 |
| 3x0090 | Air flow Slave controller 5 | 0 | 32767 | 0 | | Actual airflow slave controller 5 |
| 3x0091 | Air flow Slave controller 6 | 0 | 32767 | 0 | | Actual airflow slave controller 6 |
| 3x0092 | Air flow Slave controller 7 | 0 | 32767 | 0 | | Actual airflow slave controller 7 |
| 3x0093 | Air flow Slave controller 8 | 0 | 32767 | 0 | | Actual airflow slave controller 8 |
| 3x0094 | Air flow Slave controller 9 | 0 | 32767 | 0 | | Actual airflow slave controller 9 |
| 3x0095 | Air flow modbus sensor, lps * 10. | 0 | 32767 | 0 | | Actual airflow from modbus sensor, lps*10 |
| 3x0096 | Water cooling regulator signal. | 0 | 10000 | 0 | | Actual water cooling signal (%) |
| 3x0097 | Water heating regulator signal. | 0 | 10000 | 0 | | Actual water heating signal (%) |
| 3x0098 | Airflow demand signal | 0 | 10000 | 0 | | Actual airflow demand signal |
| 3x0099 | Air flow set point master regulator | 0 | 32767 | 0 | | Actual airflow setpoint master controller |
| 3x0100 | Pressure slave 1 | -4000 | 25000 | 0 | | Actual pressure from slave 1 |
| 3x0101 | Pressure slave 2 | -4000 | 25000 | 0 | | Actual pressure from slave 2 |
| 3x0102 | Pressure slave 3 | -4000 | 25000 | 0 | | Actual pressure from slave 3 |
| 3x0103 | Pressure slave 4 | -4000 | 25000 | 0 | | Actual pressure from slave 4 |
| 3x0104 | Pressure slave 5 | -4000 | 25000 | 0 | | Actual pressure from slave 5 |
| 3x0105 | Pressure slave 6 | -4000 | 25000 | 0 | | Actual pressure from slave 6 |
| 3x0106 | Pressure slave 7 | -4000 | 25000 | 0 | | Actual pressure from slave 7 |
| 3x0107 | Pressure slave 8 | -4000 | 25000 | 0 | | Actual pressure from slave 8 |
| 3x0108 | Pressure slave 9 | -4000 | 25000 | 0 | | Actual pressure from slave 9 |
| 3x0109 | Pressure duct | -4000 | 25000 | 0 | | Actual duct pressure |
| 3x0110 | Master min airflow | 0 | 32767 | 0 | | Min airflow master |
| 3x0111 | Master max airflow | 0 | 32767 | 0 | | Max airflow master |
| 3x0112 | VOC error status | -32768 | 32767 | 0 | | VOC error status |
| 3x0113 | Condensation input value | 0 | 1000 | 10000 | | Actual condensation sensor value |
| 3x0160 | Min airflow | 0 | 32767 | 0 | | Min airflow |
| 3x0161 | Max airflow | 0 | 32767 | 0 | | Max airflow |
| 3x0162 | Minutes since last calibration | 0 | 32767 | 5000 | | Actual minutes since last calibration |
| 3x0163 | Room temp measured | -5000 | 8000 | 2000 | | Actual measured room temperature |
| 3x0198 | Simulated motor feedback | 0 | 32767 | 0 | | Actual simulated motor feedback signal |
| 3x0200 | Uptime year | 0 | 32767 | 0 | | Actual uptime years |
| 3x0201 | Uptime hours | 0 | 8760 | 0 | | Actual uptime hours |
| 3x0202 | Uptime minutes | 0 | 60 | 0 | | Actual uptime minutes |
| 3x0203 | VOC reboot counter | 0 | 32767 | 0 | | VOC reboot counter |
| 3x0204 | VOC fault pending counter | 0 | 32767 | 0 | | VOC fault pending counter |

| Holding | | | | | | |
|---------|---------------------------|--------|-------|-------|---|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0001 | Component Name ID | 19 | 19 | 19 | | Component Name ID |
| 4x0002 | Component name | -32768 | 32767 | 30547 | | Component name |
| 4x0003 | Component name | -32768 | 32767 | 26469 | | Component name |
| 4x0004 | Component name | -32768 | 32767 | 28271 | | Component name |
| 4x0005 | Component name | -32768 | 32767 | 21792 | | Component name |
| 4x0006 | Component name | -32768 | 32767 | 26990 | | Component name |
| 4x0007 | Component name | -32768 | 32767 | 28518 | | Component name |
| 4x0008 | Component name | -32768 | 32767 | 28018 | | Component name |
| 4x0009 | Component name | -32768 | 32767 | 21024 | | Component name |
| 4x0010 | Component name | -32768 | 32767 | 28527 | | Component name |
| 4x0011 | Component name | -32768 | 32767 | 8301 | | Component name |
| 4x0012 | Component name | -32768 | 32767 | 28483 | | Component name |
| 4x0013 | Component name | -32768 | 32767 | 29806 | | Component name |
| 4x0014 | Component name | -32768 | 32767 | 28530 | | Component name |
| 4x0015 | Component name | -32768 | 32767 | 27756 | | Component name |
| 4x0016 | Component name | -32768 | 32767 | 29285 | | Component name |
| 4x0017 | Component name | -32768 | 32767 | 12576 | | Component name |
| 4x0018 | Application ID | 0 | 999 | 15 | | Controller application |
| 4x0019 | Controller modbus address | 1 | 247 | 1 | | Controller Modbus ID |
| 4x0020 | Baud rate | 0 | 2 | 2 | 0=9600, 1=19200, 2=38400 | Communication setting: Modbus Baud rate |
| 4x0021 | Parity | 0 | 2 | 2 | 0=Odd, 1=Even, 2=None | Communication setting: Modbus Parity |
| 4x0022 | Stop bits | 1 | 2 | 1 | 1=1 Stop Bit, 2=2 Stop Bits | Communication setting: Slave unit Modbus ID |
| 4x0023 | Slave id | 1 | 9 | 1 | | Communication setting: Slave unit Modbus ID |
| 4x0024 | Identification number | 0 | 32767 | 0 | | Identification number |
| 4x0025 | Controller type | 0 | 1 | 0 | 0=Master controller, 1=Slave controller | Controller type |

| Holding | | | | | | |
|---------|---------|-----|-----|------|---|----------------|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0026 | App AO1 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |
| 4x0027 | App AO2 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |
| 4x0028 | App AO3 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |
| 4x0029 | App DO1 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |

| Holding | | | | | | |
|---------|------------------------------|-----|-------|------|---|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0030 | App DO2 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |
| 4x0031 | App DO3 | 0 | 19 | 0 | "0=Output not used, 1=Water cooling, 2=Water heating, 3=Water change over 2 pipe, 4=Water change over 4 pipe, 5=Water cooling primary sequence, 6=Water cooling secondary sequence, 7=Water heating primary sequence, 8=Water heating secondary sequence, 9=Discrete supply air, pulsed, 10=Discrete extract air, pulsed, 11=Discrete supply air, fixed on/off, 12=Discrete extract air, fixed on/off, 13=Power supply, 14=Continues supply air, 15=Continues extract air, 16=Flow demand supply air (for analogue outputs with no feedback), 17=Flow demand extract air (for analogue outputs with no feedback), 18=Supply air for Parasol adapt slaves, 19=Light control" | Operating Mode |
| 4x0032 | Input 1 usage | 0 | 5 | 0 | "0=Don't use external temperature sensor, 1=Use external temperature input for room temperature, 2=Use external temperature input for change over, 3=Use external temperature input for reading, no function, 4=Use input for window contact, normal open, 5=Use input for window contact, normal closed" | Input 1 configuration. Room temp, Change over temp, Read only temp or Window contact |
| 4x0033 | Input 3 usage | 0 | 2 | 0 | 0=Not used, 1=CO2 sensor 0-10V, 2=CO2 sensor 2-10V | Input 3 configuration, Used for CO2 input |
| 4x0034 | Input 4 usage | 0 | 6 | 0 | 0=Not used, 1=Keycard, normal open, 2=Keycard, normal closed, 3=Window contact, normal open, 4=Window contact, normal closed, 5=Change over, normal open, 6=Change over, normal closed | Input 4 configuration. Keycard switch, Window contact or Change over switch |
| 4x0035 | Room temperature sensor use. | 0 | 3 | 0 | "0=Use mean value of sensor module(s), 1=Use sensor module with ID 1, 2=Use external temperature input, 3=Use mean value of SM(s) and external sensor" | Defines witch temperature to use. Mean value from SM, SM ID0, External Temp, Mean of SM and Ext temp. |
| 4x0036 | Occ mode | 0 | 2 | 0 | 0=Use occupancy sensor, 1=Always occupied, 2=Always unoccupied | Defines occupancy mode. Auto, Forced OCC or Forced UNOCC |
| 4x0037 | Occ off delay | 60 | 3600 | 600 | | Occupancy off delay in s |
| 4x0038 | Occ on delay | 1 | 600 | 30 | | Occupancy on delay in s |
| 4x0039 | Occupancy trig level | 0 | 32767 | 20 | | Occupancy trig level |

| Holding | | | | | | |
|---------|------------------------|-----|------|------|--|---|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0040 | Commissioning mode. | 0 | 516 | 0 | 0=Commissioning not active, 1=Min air flow unoccupied, 2=Min air flow occupied, 3=Max air flow, 4=Min air flow holiday, 256=Open cooling valve, 512=Open heating valve | Commissioning mode selection. |
| 4x0041 | Commissioning max time | 0 | 5000 | 0 | | Max comissioning time in hours |
| 4x0042 | Set point Cool Occ | 500 | 8000 | 2300 | | Cooling setpoint in occupancy mode (degrees celsius*100) |
| 4x0043 | Set point Heat Occ | 500 | 8000 | 2100 | | Heating setpoint in occupancy mode (degrees celsius*100) |
| 4x0044 | Set point Cool UnOcc | 500 | 8000 | 2400 | | Cooling setpoint in unoccupancy mode (degrees celsius*100) |
| 4x0045 | Set point Heat UnOcc | 500 | 8000 | 2000 | | Heating setpoint in unoccupancy mode (degrees celsius*100) |
| 4x0046 | Set point Cool SNC | 500 | 8000 | 2400 | | Cooling setpoint summer night cooling (degrees celsius*100) |
| 4x0047 | Set point Heat SNC | 500 | 8000 | 1500 | | Heating setpoint summer night cooling (degrees celsius*100) |

| Holding | | | | | | |
|---------|---------------------------------------|--------|-------|-------|--|--|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0048 | Set point Cool Holiday | 500 | 8000 | 2500 | | Cooling setpoint in holiday mode (degrees celsius*100) |
| 4x0049 | Set point Heat Holiday | 500 | 8000 | 1800 | | Heating setpoint in holiday mode (degrees celsius*100) |
| 4x0050 | Room temperature offset | -1000 | 1000 | 0 | | Room temp offset (Degrees celsius*100) |
| 4x0051 | SM SP offset step size | 0 | 300 | 100 | | "Sensor module Offset step size (degrees celsius*100) Default 100 = 1 degree" |
| 4x0052 | Cooling boost delay | 0 | 60 | 10 | | Two step cooling delay in minutes |
| 4x0053 | Heating boost delay | 0 | 60 | 10 | | Two step heating delay in minutes |
| 4x0054 | Change over 2 act temp | 0 | 8000 | 0 | | Actual Change over temp (degrees celsius*100) |
| 4x0055 | Heat type | 0 | 1 | 0 | 0=Normal (water actuator), 1=Radiator | Defines heat type Water actuator or Radiator |
| 4x0056 | Air flow max | 0 | 32767 | 2000 | | Configured max airflow in l/s*10 |
| 4x0057 | Air flow min Occ | 0 | 32767 | 150 | | Configured min occupancy airflow in l/s*10 |
| 4x0058 | Air flow min UnOcc | 0 | 32767 | 50 | | Configured min unoccupancy airflow in l/s*10 |
| 4x0059 | Air flow min Holiday | 0 | 32767 | 50 | | Configured min holiday airflow in l/s*10 |
| 4x0061 | Air flow moving average time (hours). | 0 | 24 | 1 | | Air flow moving average time (hours). |
| 4x0062 | Low pressure alarm limit | 0 | 10000 | 0 | | Configured low pressure alarm limit in dpa |
| 4x0063 | Vent boost delay | 0 | 200 | 72 | | Configured ventilation boost delay time in hours |
| 4x0064 | Vent boost time | 0 | 60 | 5 | | Configured ventilation boost time in minutes |
| 4x0065 | Valve exercise interval | 0 | 96 | 48 | | Configured valve exercise interval in hours |
| 4x0066 | Min pressure for cooling | 0 | 30000 | 250 | | Configured minimum pressure to allow cooling in dpa |
| 4x0067 | Air cooling sequence | 0 | 2 | 1 | "0=Control temperature in three steps, air, water then air again, 1=Control temperature with air before water" | Defines cooling sequence Water-Air or Air-Water |
| 4x0068 | K-factor on damper short side | -32768 | 32767 | 0 | | K-factor short side ' 100 |
| 4x0069 | K-factor on damper long side | -32768 | 32767 | 0 | | K-factor long side ' 100 |
| 4x0070 | Heating P-band | 0 | 1500 | 300 | | Regulator setting P-band heating (degrees*100) |
| 4x0071 | Cooling P-band | 0 | 1500 | 300 | | Regulator setting P-band cooling (degrees*100) |
| 4x0072 | Heating I-time | 0 | 1200 | 20 | | Regulator setting Heating I-time (minutes) |
| 4x0073 | Cooling I-time | 0 | 1200 | 20 | | Regulator setting Cooling I-time (minutes) |
| 4x0076 | P-band airflow regulator | 0 | 32767 | 800 | | Regulator setting Airflow P-band (l/s*10) |
| 4x0077 | I-time airflow regulator | 0 | 32767 | 45 | | Regulator setting Airflow I-time (seconds) |
| 4x0079 | Change over 2 hyst temp | 0 | 1000 | 500 | | Change over temperature hysteresis (Degrees*100) |
| 4x0080 | Change over 4 low limit | 0 | 1000 | 550 | | CCO valve deadzone low limit (V*100) |
| 4x0081 | Change over 4 hi limit | 0 | 1000 | 650 | | CCO valve deadzone high limit (V*100) |
| 4x0082 | Internal LED mode | 0 | 1 | 1 | | Internal LED operation mode |
| 4x0083 | SM offset LED mode | 0 | 2 | 2 | | Sensor module offset LED operation mode |
| 4x0084 | SM offset LED active | 1 | 999 | 20 | | Sensor module offset LED activation |
| 4x0085 | SM LED brightness active | 0 | 10000 | 10000 | | Configured led brightness on SM active state (%*100) |
| 4x0086 | SM LED brightness inactive | 0 | 10000 | 2000 | | Configured led brightness on SM inactive state (%*100) |
| 4x0088 | Damper action emergency | 0 | 1 | 0 | 0=Close damper, 1=Open damper | Damper emergency action mode |
| 4x0089 | Air quality low limit ppm | 0 | 2000 | 600 | | CO2/VOC low limit ppm |

| Holding | | | | | | |
|---------|---|--------|-------|------|--|--|
| ID | Name | Min | Max | Init | Settings | Description |
| 4x0090 | Air quality high limit ppm | 0 | 2000 | 1200 | | CO2/VOC high limit ppm |
| 4x0091 | PPM/V for CO2 or VOC analog sensor | 0 | 1000 | 200 | | Configured ppm/v value from analog Co2/ VOC sensor |
| 4x0092 | VOC sensor use | 0 | 1 | 1 | 0=VOC sensor not used, 1=VOC value used if sensor is present | VOC sensor mode. Off/Auto |
| 4x0093 | Low lim AO1 | 0 | 1000 | 200 | | Analog output 1 low limit (v*100) |
| 4x0094 | Hi lim AO1 | 0 | 1000 | 800 | | Analog output 1 high limit (v*100) |
| 4x0095 | Low lim AO2 | 0 | 1000 | 200 | | Analog output 2 low limit (v*100) |
| 4x0096 | Hi lim AO2 | 0 | 1000 | 1000 | | Analog output 2 high limit (v*100) |
| 4x0097 | Low lim AO3 | 0 | 1000 | 200 | | Analog output 3 low limit (v*100) |
| 4x0098 | Hi lim AO3 | 0 | 1000 | 700 | | Analog output 3 high limit (v*100) |
| 4x0099 | Coil mirror | -32768 | 32767 | 0 | | Coil mirror |
| 4x0100 | Modbus master delay time | 1 | 500 | 1 | | Modbus master delay time |
| 4x0101 | Restore settings (write 1111) | 0 | 32767 | 0 | | Restore settings (write 1111) |
| 4x0102 | Save settings (write 2222) | 0 | 32767 | 0 | | Save settings (write 2222) |
| 4x0103 | Airflow demand min | 0 | 32767 | 0 | | Configured min value airflow demand |
| 4x0104 | Airflow demand max | 0 | 32767 | 0 | | Configured max value airflow demand |
| 4x0105 | EA offset | -10000 | 10000 | 0 | | Configured Extract air offset (%*100) |
| 4x0106 | Digital out 1 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Digital output 1 |
| 4x0107 | Digital out 2 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Configuration output 2 |
| 4x0108 | Digital out 3 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Digital output 3 |
| 4x0109 | Analog out 1 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Analog output 1 |
| 4x0110 | Analog out 2 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Analog output 2 |
| 4x0111 | Analog out 3 option | 0 | 1 | 0 | 0=Output is normally open (default), 1=Output is normally closed. (Means inverted) | Used to configure function on Analog output 3 |
| 4x0112 | Ignore Occupancy SM (bit code) | 0 | 1023 | 0 | | Ignore Occupancy sensor module (bit code) |
| 4x0113 | Slave air function | 0 | 1 | 0 | 0=Slave is variable, 1=Slave is on/off | Slave air function |
| 4x0114 | Air-water-air break-point A | 0 | 10000 | 3000 | | Cooling/Heating sequence breakpoint A (%*100) |
| 4x0115 | Air-water-air break-point B | 0 | 10000 | 8000 | | Cooling/Heating sequence breakpoint B (%*100) |
| 4x0116 | Cold draft protection level | 0 | 10000 | 3000 | | Cold draft protection level (%*100) |
| 4x0117 | Cold draft protection limit to turn off | 0 | 10000 | 5000 | | Cold draft protection limit to stop (%*100) |
| 4x0118 | Actuator period time | 60 | 1800 | 600 | | Defines Actuator PWM period time in seconds |
| 4x0119 | Condensation low trig level | 0 | 1000 | 500 | | Condensation trig level (kOhm) |
| 4x0120 | Condensation hi trig level | 0 | 1000 | 900 | | Condensation release level (kOhm) |
| 4x0121 | Room temp central | -5000 | 8000 | 0 | | Room temp central |
| 4x0122 | Reset timer temperature offset | 0 | 24 | 0 | | Temperature offset reset time (h) |
| 4x0123 | Continuous airflow type | 0 | 2 | 0 | | Airflow regulation mode |
| 4x0124 | Motor stroke time | 1 | 1000 | 100 | | Defines motor stroke time (s) |

Trouble shooting

Alarm List

| Alarm no. | Type of alarm | Probable cause |
|-----------|------------------------------|---|
| Alarm no. | Type of alarm | Comment |
| Alarm 1 | Supply voltage low | Low supply voltage, undersized transformer, voltage drop in long cables. Risk of reduced function |
| Alarm 2 | Supply voltage critical low | See above, large risk of reduced function |
| Alarm 3 | Ext temp missing | Temp. sensor not connected |
| Alarm 4 | Ext temp error | Temp. sensor defective |
| Alarm 5 | Condensation sensor error | Condensation sensor defective |
| Alarm 6 | SM temp sensor error | SM temp sensor defective |
| Alarm 7 | SM button error | SM temp button defective |
| Alarm 8 | CO2 sensor missing | CO2 sensor not connected |
| Alarm 9 | VOC Error | VOC sensors, incorrect value |
| Alarm 10 | Low pressure | One of the pressure sensors measure a pressure below the permitted |
| Alarm 17 | SM comm error | Communication error sensor module, check addressing |
| Alarm 18 | Slave comm error | Slave unit not connected |
| Alarm 19 | Pressure sensor comm error | Communication error pressure sensor, check addressing of the pressure sensor |
| Alarm 20 | VOC sensor comm error | VOC sensor not connected |
| Alarm 21 | No master request (slave) | The slave unit cannot find a Master to relate to. |
| Alarm 22 | Slave incompatible version | Software version in slave unit is different to the one in the master unit |
| Alarm 25 | Heating comfort alarm | Room setpoint cannot be reached, even though the output to the heating actuator has been 100% for x minutes |
| Alarm 26 | Cooling comfort alarm | Room setpoint cannot be reached, even though the output to the cooling actuator has been 100% for x minutes |
| Alarm 27 | Temp. Setpoint overlap alarm | Overlapping set values for temperature |
| Alarm 28 | Air quality comfort alarm | Permitted PPM value exceeded during x minutes |
| Alarm 29 | Condensation | The condensation sensor has made the circuit, condensate water or short circuit |
| Alarm 33 | 24 V Out 1 overload error | Overloaded output |
| Alarm 34 | 24 V Out 2 overload error | Overloaded output |
| Alarm 35 | 24 V Out 3 overload error | Overloaded output |
| Alarm 41 | Slave input sum alarm | Input alarm from slave unit |
| Alarm 42 | Slave output sum alarm | Output alarm from slave unit |