CASA R5 Genius

Technical catalogue



QUICK FACTS

- CASA Genius control system
- Automatic rotor speed control for demand controlled humidity function as standard
- Automatic summer function and passive cooling
- Anti-frost protection ensures continuous ventilation
- External coils for heating and cooling as an option
- Can be connected to the automated building management system (I/O/Modbus)
- Mounted on the wall or ceiling

| Air flow range | 30-117 l/s 108-421 m³/h |
|---------------------------------------|--|
| Dimensions, w x l x h | 598 x 600 x 598 mm |
| Duct outlets | 4 x Ø 160 mm |
| Cooker hood outlet | Ø 125 mm |
| Energy calculations and acoustic data | procasa.swegon.com |
| Connection power | 1040 W 240 W |
| Power connection | 230 V, 50 Hz, 10 A |
| Fans | 220 W, EC |
| Filters | ISO ePM1 55% (F7) + ISO coarse (G3) filters for supply air and ISO ePM1 55% (F7) for extract air |
| Colour | Exterior White, RAL 9016 (corresponds to NCS S0502-G50Y) |



Content

| Technical description | 3 |
|-----------------------|----|
| CASA Genius control | 6 |
| Design data | 8 |
| Air flows | 10 |
| Acoustic data | 10 |
| Dimensions and weight | 11 |
| Functional diagram | 12 |
| External connections | 14 |
| Internal connections | 15 |
| Installation options | 16 |
| Product codes | 18 |





Technical description

Swegon CASA R5 Genius

Air handling unit with rotary heat exchanger (598 x 600 x 598 mm, \emptyset 160 mm) suitable installation in homes (240 m²). The unit's sound level is low. The intelligent demand-controlled humidity function is standard.

Indoor environmental quality

Ventilation control

The unit is controlled steplessly with automation functions to quarantee the best indoor environmental quality. The user can select five operating modes home, away, boost, travelling and home+ by using control panel, cooker hood or Swegon CASA app. Operation modes can be automated with unit's weekly programs.

Temperature control

The supply air temperature is controlled with heat exchanger and if needed with optional heating or cooling element.

The unit has automatic summer time detection. The function sets lower supply air temperature setpoint and boost ventilation in order to bring more fresh outdoor air to the apartment during summer nights.

Device models without internal post-heating

Units which are not equipped with an internal heater (R05VL00G00H, R05VR00G00H) are not suitable for cold conditions without an external heater.

If the heat exchanger cannot produce sufficiently warm supply air, the supply air flow is reduced in proportion to the exhaust air flow to maintain the set temperature. For this reason, negative pressure may form in the apartment, and ventilation may drop to minimum speed.



Available variants

Standard units are available in following variants:

- Unit with 800 W postheater
 L (exhaust air left) / R (exhaust air right)
- Unit without postheater
 L (exhaust air left) / R (exhaust air right)



Components

Fans

CASA R5 is equipped with energy efficient EC fans.

Filter

The ventilation unit is equipped with ISO ePM1 55% (F7) + ISO coarse (G3) filters for supply air and ISO ePM1 55% (F7) for extract air. The need of filter replacement is indicated on the control panel and on the CASA cooker hood.

Heat exchanger

The ventilation unit is equipped with a **speed controlled rotary heat exchanger**. Heath exchanger is controlled either to maintain constant supply air temperature or to achieve maximum energy efficiency (winter mode).

External connections

All connections can be made without opening the electrical box. Plug-in modules are available for external connections. Wide variety of IO functions are available.

The ventilation unit is equipped with In-build Modbus. Modbus cabling can be made easily with external cable (SEC) or module (SEM). Unit can be fully controlled with Modbus and all external IO's can be configured to Modbus usage.

Protective functions

The heat exchanger freeze protection

The defrosting function guarantees continuous ventilation and maintains units performance even during extreme conditions. If reheat can't maintain sufficient supply air temperature, the air flows are reduced.

The fan overheating protection

The fan overheat protection stops the fan if the temperature rises too high and is reseted automatically. If protection stops the fans an alarm is generated.

Rotor guard

Rotor guard detects that the rotor is working. Malfunction generates an alarm.

Cold supply air

The ventilation unit has built-in condensation protection. If the supply air is too cold, the ventilation unit stops and an alarm is generated

High temperature

If supply air or units internal temperature is detected dangerously high the unit is stopped and an alarm is generated.

Temperature sensors

If a sensor fault is detected, an alarm is generated. If the faulted sensor is critical the ventilation unit is stopped. The ventilation unit returns to normal mode once the fault has been corrected.






The delivery includes

- Ventilation unit
- Anti-vibration mountings (2 pcs.)
- Wall mounting bracket
- Condensate discharge hose
- Quick Guide
- Installation and commissioning instruction
- Product fiche

Standard connections

- Power cord with earthed plug (2 m)
- Cable for SEC/SEM connection module with RJ45 connector (2m)
- Modular cable with RJ9 connector (1.5 m)
- Freely configurable I/O contacts for connection of accessories (2 pcs.)



- 7. Rotor package
- 7.1 Brush seals
- 7.2 Drive wheel
- 7.3 Rotor motor
- 7.4 Drive belt
- 8. Door
- 9. Condensate discharge hose
- 10. Wall mounting bracket
- 11. Anti-vibration mountings (2 pcs.)
- 12. Sensor package





Swegon CASA Genius

Intelligent control of the ventilation

With Swegon CASA Genius residents can monitor the indoor air quality (RH, CO2, VOC, °C), adjust ventilation to their wishes or let the intelligent control to adjust ventilation automatically while saving energy and providing fresh and healthy indoor air.



The Swegon CASA control panel (GC10)

Wall-mounted touch screen for external or flush mounting. From the touch screen user can monitor ventilation, change ventilation mode, change the settings and commission the ventilation unit. The screen can be connected to the home WLAN, enabling the ventilation to be controlled remotely from a Swegon CASA mobile app



The Swegon CASA app

With Swegon CASA app residents can use all the control functions remotely from their own smartphone. Users get more information about their home's air quality as well as valuable instructions and advice about the ventilation (requires Swegon Genius control panel).



The CASA Service app

for quick and easy commissioning. The app works locally together with the ventilation unit and doesn't require connection to network. The app defines the I/O connections, presets the fan speeds that correspond to specified air volumes, as well as automatically sets air volumes for home and boost mode. Finished settings can be saved in the app and copied to the next apartment (requires Swegon Genius control panel).



Swegon CASA cooker hood

With cooker hoods, it is possible to control the ventilation unit's operating mode (home, away, boost), the cooker hood's shut-off damper and the lighting in the hood. The system balances the ventilation automatically when using the cooker hood.




The Swegon CASA HOME/AWAY/BOOST control switch (GC04)

Wall-mounted control switch for selecting boost, home and away modes.



Home automation

Can be connected to the home automation for centralised monitoring and control, either directly via configurable I/O or with the aid of a separate Modbus connection module (SEM).





Basic modes

You can switch as required to an appropriate operating mode or let the pre-programmed weekly clock switch operating mode according to the diurnal rhythm you want.



Home

Normal air flow. Sufficient amount of fresh indoor air to ensure the wellbeing of the residents and the structural building elements when there are people in the home.



Home+

Higher air flow. Can be used when more ventilation is required. The home owner can change the efficiency of the operating mode from the settings.



Boost

High air flow. Used if the ventilation requirement increases, for example, when cooking, taking a bath or drying laundry, or when an unusually large number of people are in the home.



Away

Low air flow. Reduces the energy consumption when nobody is present in the home.



Travelling

Very low air flow and lower supply air temperature. Used when nobody is present in the home.

Automatic functions

The intelligent ventilation monitors the quality of the indoor air and adjusts the ventilation automatically.



RH Humidity 35%

Automatic RH system included as standard

Humidity automation removes damaging moisture. The intelligent control analyses the indoor air continuously and regulates the ventilation steplessly so that excess moisture is removed, for example when you are washing.



CO₂ Carbon dioxide 520 PPM

Automatic CO2 system as optional equipment

Automatically lowers the ventilation and saves energy when nobody is in the home. When the residents are at home, the ventilation is automatically boosted to bring exactly the right amount of fresh air into the home.



VOC Air quality 950 PPM


Automatic VOC system as optional equipment

The automatic air quality system boosts the ventilation if pollution, odours or vapours (evaporating organic compounds) are detected in the indoor air.






Design data



CASA R5 L, duct connections and cooker hood connected to the ventilation unit's kitchen duct connection.



CASA R5 L, duct connections and cooker hood connected to external ceiling fan.



Note! Always check the unit design (L/R) and correct duct sequence in the installation instructions.









Energy calculation, functional diagram and acoustic data on ProCASA.

procasa.swegon.com










3D models and CAD dimension sketches for all Swegon CASA products are available from MagiCloud. You can download DXF files directly from MagiCloud or use a MagiCAD plugin to transfer dimension sketches to the Revit and AutoCAD software packages.

www.magicloud.com





Air flows



Note! If the humidity production in the apartment is high, the boost margin must be at least 30%.

Acoustic data

See acoustic data on ProCASA. procasa.swegon.com








Dimensions and weight

Dimensions

R5






Functional diagram

Functional diagram

R5



| Device | Description | Modbus register |
|----------|---|-------------------------------|
| T1 | Temperature sensor, outdoor air | 3x6201 (0,1°C) |
| T3 | Temperature sensor, extract air | 3x6204 (0,1°C) |
| T4 | Temperature sensor, supply air | 3x6203 (0,1°C) |
| T5 | Temperature sensor, exhaust air | 3x6205 (0,1°C) |
| TZ01 | Manual overheat protection 70°C post heater | Alarm 3x6117 |
| TZA1 | Automatic overheat protection 55°C post heater | Alarm 3x6117 |
| Filter 1 | Fresh air filters ISO ePM1 55% (F7) + ISO coarse (G3) | Service reminder info 3x6129 |
| Filter 2 | Extract air filter ISO ePM1 55% (F7) | Service reminder info 3x6129 |
| F1 | Extract fan including internal overheat protection. | Control 3x6304(%), RPM 3x6306 |
| F2 | Supply fan including internal overheat protection. | Control 3x6303(%), RPM 3x6305 |
| PH | Post heater (800W/-), controlled steplessly according to demand (optional) | Control 3x6317 (%) |
| HE | Rotating heat exchanger (Rotor) | |
| НЕ М | A heat exchanger motor which speed is steplessly controlled based on the temperature and humidity of the supply air | Control 3x6332 (0.1xRPM) |
| S1 | Use Switch. Note! power off the unit by removing the socket from the Mains when Service | |
| RH | Humidity sensor for RH automation | RH 3x6214 |
| TSP | Extract air temperature sensor for humidity measurement | |
| CH_EXT | Extra duct connection for the cooker hood. Duct bypasses the heat exchanger. Note! Do not connect the general ventilation of the kitchen here. Connect the hood status information to the ventilation unit. (Duct connection is plugged at the factory) | |
| DRAIN | Condensate discharge drain. Connect the water trap and drain hose to the condensate connection. Check the operation of the water trap. | |






Functional diagram

Duct actuators

- FIELD CONFIGURATION AU
- FIELD CONNECTION SU
- ◆ FYSICAL CONNECTION
- ALTERNATIVE CONNECTION
 (Note: an additional relay is required for DO outputs)



| Device | Description |
|----------|---|
| T6-T9 | Temperature sensor. Connection to the SET module. The sensor must be defined on the control panel. |
| SD1, SD2 | Duct Plate for Outdoor/Exhaust duct. |
| FLK | Duct filter in combination with an electric pre heater (SDHE) |
| SDHWM | Ground Liquid preheating/cooling coil for outdoor air duct. (Inc SET, heating/cooling coil, sensor) |
| SDHE | Electrical duct heater for Supply/Outdoor air duct (Inc. SET, duct heater and sensors) Note! A duct filter (FLK) is required for the preheater. |
| SDHW | Heating coil for supply air duct (Inc. SET, three-way valve + actuator, heating coil, sensors). |
| SDCW | Cooling coil for supply air duct (Inc. SET, three-way valve + actuator, cooling coil, sensors). |
| | |
| CO2 | CO2 sensor for CO2 automation |
| VOC | VOC sensor for VOC automation |
| SEM | Modbus module (Inc. 2m RJ-45 cable) |
| SEC | IO extension module (Inc. 2m RJ-45 cable) |
| SET | Connection module for duct batteries and temperature sensors. (Inc. 2 x 3m RJ-45 cable) |
| APP | Swegon CASA mobile application for ventilation control and monitoring. Requires a Genius control panel (GC10) to operate. |
| UP GC10 | Genius control panel that can be connected to Swegon CASA application via WiFi. |
| GC04 | Control switch to select boost, home and away mode. |
| GC03 | Control switch to select boost mode. |
| СН | Cooker hood. The CASA hood is connected to the ventilation unit with a modular cable. With other hoods, you can control the cooking function with a switch input that is determined for the function. |






External connections

External connections

CASA Genius



SEC IO extension cable with Modbus RTU

SEM IO extension module with relay and Modbus RTU (input and output connections)


SET IO extension module for control of external accessories





Internal connections

R5



| Device | Description |
|---------|--|
| T1 | Temperature sensor, outdoor air |
| T3 | Temperature sensor, extract air |
| T4 | Temperature sensor, supply air |
| T5 | Temperature sensor, exhaust air |
| PH | Post heater, steplessly, controlled steplessly according to demand |
| TZ01 | Manual overheat protection 70°C post heater |
| TZA1 | Automatic overheat protection 55°C post heater |
| F1 | Extract fan including internal overheat protection. |
| F2 | Supply fan including internal overheat protection. |
| НЕ М | A heat exchanger motor which speed is steplessly controlled based on the temperature and humidity of the supply air |
| S1 | Use Switch. Note! power off the unit by removing the socket from the Mains when Service |
| RH | Humidity sensor for RH automation |
| TSP | Extract air temperature sensor for humidity measurement |
| CO2 | CO2 sensor for CO2 automation (accessory) |
| VOC | VOC sensor for VOC automation (accessory) |
| UI | Connectors for connecting the control panel and/or CASA cooker hood. One connection point is wired outside the unit. |
| SEC/SEM | Connector for connecting the SEC or SEM module. The connection point is wired outside the unit. |
| SET 1&2 | Connectors for connecting the SET module |
| 5V/24V | 24V voltage output, which can be changed to 5V output with a jumper on the circuit board. |
| IO 1&2 | Two general-purpose IO connectors. Connectors must be configured for the desired functions. |
| GND | Ground for IO connections. |





Installation options

Ventilation unit installation site


The temperature in the space where the unit will be installed must be more than +10 °C. Due to the risk of disruptive noise, the ventilation unit should not be installed on the wall towards the living room or bedroom.

Wall mounting

A wall mountin bracket is supplied together with the ventilation unit.

If it is a question of a light partition wall, the wall must be reinforced with horizontal studs (A) that support the weight of the ventilation unit. In addition, Swegon also recommends that the wall be insulated with mineral wool or similar insulation (B) for preventing sound from propagating to other rooms.

Screw the wall mount firmly in horizontal position onto the wall where a wall stud will support the weight of the unit. Lift up the ventilation unit onto the wall mounting bracket so that the ears on the bracket engage in the corresponding notches at the top on the backside of the unit. Set the final position of the ventilation unit with the help of the adjustable anti-vibration mountings so that the ventilation unit tilts slightly backward.



Ceiling mounting

The ventilation unit can also be mounted in a ceiling mounting frame (available as an accessory) on the ceiling.

The ceiling mounting frame must not be used as part of a support structure for the ducts, the duct support must be sufficient even without the support effect provided by the ceiling mounting frame.









Product codes

R5

| Product | Product code | GTIN |
|---------------------------|--------------|---------------|
| CASA R5 Genius L 800W RH | R05VL08G00H | 6430080090235 |
| CASA R5 Genius R 800W RH | R05VR08G00H | 6430080090259 |
| CASA R5 Genius L ex.el RH | R05VL00G00H | 6430080090228 |
| CASA R5 Genius R ex.el RH | R05VR00G00H | 6430080090242 |

Accessories

| Product | Product code | GTIN |
|------------------------------------|--------------|---------------|
| Ceiling mounting frame | 10212KA | 6415879063072 |
| Mounting frame with vapour barrier | 10212YP | 6415879063041 |
| Water trap | UVLL | 6415879069302 |
| Condensate discharge tube | CDH3 | 6415879066776 |





CASA R - Accessories

| Control accessories | Part no. | GTIN |
|--|---|--|
| GC10 CASA Genius control panel and WiFi | GC10 | 643008009084 |
| GC10 control panel + 10 m long cable | GC14 | 643008009085 |
| GC10 control panel + 10 m long cable + frame | GC15 | 643008009086 |
| GC10 control panel + frame | GC16 | 643008009087 |
| Frame for control panel GC10 | 102SAK | 6415879066752 |
| CASA Genius boost/home/away control button | GC04 | 643008009001 |
| | _ | |
| Building automation | Part no. | GTIN |
| Modbus connection module | SEM | 6415879067346 |
| Connection cable (configurable I/O) for Genius ventilation units | SEC | 6415879067353 |
| Room temperature sensor, total package with connection unit for ventilation units. The sensor is installed on the wall or in a recessed junction box (60 mm between holes). | WSTC | 6415879069395 |
| | . | OT!\\ |
| Automatic functions | Part no. | GTIN |
| RH + CO2 automation | SRHCO2 | 6415879066936 |
| RH + VOC automation | SRHVOC | 6415879066943 |
| | Part no. | GTIN 6415879068053 |
| Cooling coil package Ø160 | SDCW160 | 6415879068053 |
| Cooling coil package Ø160 Waterborne air heaters | SDCW160 Part no. | 6415879068053 |
| Cooling coil package Ø160 Waterborne air heaters | SDCW160 | 6415879068053 |
| Waterborne air heaters Heating coil package Ø 160 | Part no. SDHW160 | 6415879068053 GTIN 6415879068046 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump | Part no. SDHW160 Part no. | 6415879068053 GTIN 6415879068046 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump | Part no. SDHW160 | 6415879068053 GTIN 6415879068046 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 | Part no. SDHW160 Part no. | 6415879068053 GTIN 6415879068046 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater | Part no. SDHW160 Part no. SDHW250F | GTIN 6415879068046 GTIN 6415879068046 GTIN 6415879068084 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 | Part no. SDHW160 Part no. SDHW250F Part no. | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 GTIN 6415879067247 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 GTIN 6415879067247 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 Duct mounted shut-off dampers | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T FLK16 | GTIN 6415879068053 GTIN 6415879068084 GTIN 6415879068084 6415879067247 6415879067483 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 Duct mounted shut-off dampers | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T FLK16 Part no. | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 GTIN 6415879067247 6415879067483 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 Duct mounted shut-off dampers Damper Ø 160 mm | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T FLK16 Part no. | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 GTIN 6415879067247 6415879067483 |
| Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 Duct mounted shut-off dampers Damper Ø 160 mm | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T FLK16 Part no. SDD160 | GTIN 6415879068053 GTIN 6415879068084 GTIN 6415879068084 GTIN 6415879067247 6415879067483 |
| Waterborne air coolers Cooling coil package Ø 160 Waterborne air heaters Heating coil package Ø 160 Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4 Electric air heater Electric heater Ø 160 Prefilter box Ø 160 mm, G4 Duct mounted shut-off dampers Damper Ø 160 mm Other accessories Connection module for control of the duct mounted air heater/cooler / control of shut-off dampers SET / power source for actuators | Part no. SDHW160 Part no. SDHW250F Part no. SDHE160-1T FLK16 Part no. SDD160 Part no. | GTIN 6415879068053 GTIN 6415879068046 GTIN 6415879068084 GTIN 6415879067247 6415879067483 GTIN 6415879069937 |



Feel good **inside**



