

Adjustment manual ECO-C

NOTE! Electrical connections may only be made by a professional electrician.

Warning! The device carries a voltage of 230 V! Disconnect from the supply voltage before adjustment.



1.

2.

10 mm

3.

4.

123,0

5.

123,0

6a

72 mm

6b

7.

8.

10 mm